


Models 100 109



- A Air suction intake and air release outlet
1 Air filter
3a Valve housing of anti-freeze device

- Mount new air filter on anti-freeze device, observing correct seat of rubber sealing ring.

Note: On model 100 the air filter is connected to the anti-freeze device by a hose line.